

## **Versión 1.2**

- Primera versión.

## **Versión 1.4**

- Corrección de una incidencia:  
Mediciones incorrectas en la entrada dos al conectar ciertos valores de resistencia.
- Mejoras en los canales de persianas:
  - Corrección de incidencias:
    - Al enviar movimiento de persiana y lamas, el movimiento se detiene para atender la orden de lamas.
    - Se desactiva el control automático de un canal ante la llegada de escenas que no tienen que ver con ese canal.
  - Nuevo control: movimiento y paro con pulsación corta (conmutado).

## **Versión 1.5**

- Se incluye el bloque funcional de NTP

## **Versión 1.6**

- Se añade un parámetro para seleccionar si las escenas guardadas se sobrescribirán o no en la siguiente descarga.

## **Versión 1.2**

- Initial version.

## **Version 1.4**

- Bug fixing  
Input 2 incorrect measurements when connecting certain resistance values.
- Shutter channels improvement:
  - Bug fixing:
    - When sending positioning orders for shutter and slats, shutter movement stops in order to move slats.
    - Automatic control is disabled when a scene order is sent to a different channel.
  - New control: movement and stop with short press (toggle).

## **Versión 1.5**

- Inclusion of NTP functional module

## **Versión 1.6**

- A new parameter has been added to select if the saved scenes are overwritten in the following download.