

#### **TECHNICAL DOCUMENTATION**

# •Zennio KNX-IP Interface

#### ZSYKIPI

### FEATURES

- KNXnet/IP tunneling protocol (up to 5 connections)
- Maximal APDU length of 254 bytes
- Ethernet 10/100 BaseT IP with RJ45 socket
- Auxiliary power supply is not required
- Integrated KNX BCU (TP1-256)
- Dimensions 67 x 90 x 36 mm (2 DIN units)
- DIN rail mounting according to IEC 60715 TH35, with fixing clamp
- Conformity with the CE, UKCA, RCM directives (marks on the side)




Figure 1: KIPI

1. Ethernet connection	2. KNX LED indicator	3. Ethernet I	ED indicator	4. Not used	5. Not used	6. KNX connector
with LED indicator						
7. Programming LED	8. Programming button		<ol><li>Factory reset button</li></ol>		10. Factory reset	
					L	ED indicator

Programming button: short press to set programming mode. If this button is held while plugging the device into the KNX bus, it enters the safe mode. Factory reset button: long press to perform a factory reset (Factory reset LED lights red for one second).

Programming LED: programming mode indicator (red). When the device enters the safe mode, it blinks (red) every half second. During the start-up (reset or after KNX bus failure) and if the device is not in safe mode, it emits a red flash.

KNX indicator LED: shows that the device is powered through the KNX bus (green color).

Ethernet indicator LED: shows that the device is connected to Ethernet and has an IP address assigned (green color).


Factory reset indicator LED: shows that the device has just executed a factory reset (red color).

Ethernet connector LED: shows that the Ethernet is linked (green color) or data is being transfered (green blinking)

GENERAL SPECIFICATIONS CONCEPT		DESCRIPTION				
Type of device		Electric operation control device				
Voltage (typical)		29 VDC SELV				
	Voltage range		21-31 VDC			
KNX supply	Maximum	Voltage	mA	mW		
		29 VDC (typical)	16	464		
	consumption	24 VDC <sup>1</sup>	20	480		
	Connection type		Typical TP1 bus connector for 0.8 mm Ø rigid cable			
External power supply		Not required				
Operation temperature		0 +55 °C				
Storage temperature		-20 +55 °C				
Operation humidity		5 95%				
Storage humidity		5 95%				
Complementary characteristics		Class B				
Protection class						
Operation type		Continuous operation				
Device action type		Type 1				
Electrical stress period		Long				
Degree of protection		IP20, clean environment				
Installation		Independent device to be mounted inside electrical panels with DIN rail (IEC 60715)				
Minimum clearances		Not required				
Response on KNX bus failure		Data saving				
Response on KNX bus restart		Data recovery				
Operation indicator		The programming LED indicates programming mode (red). The KNX LED indicates the bus connection (green). The Ethernet LED indicates the Ethernet connection with an IP assigned (green). The Factory Reset LED indicates the execution of a factory reset (red).				
Weight			74 g			
PCB CTI index		175 V	175 V			
Housing material		PC FR V0 halogen free				

<sup>1</sup> Maximum consumption in the worst-case scenario (KNX Fan-In model).

#### Attaching KIPI to DIN rail:



## SAFETY INSTRUCTIONS AND ADDITIONAL NOTES

• Installation should only be performed by qualified professionals according to the laws and regulations applicable in each country.

- Do not connect the mains voltage nor any other external voltage to any point of the KNX bus; it would represent a risk for the entire KNX system. The facility must have enough insulation between the mains (or auxiliary) voltage and the KNX bus or the wires of other accessories, in case of being installed.
- Once the device is installed (in the panel or box), it must not be accessible from outside.
- Keep the device away from water (condensation over the device included) and do not cover it with clothes, paper or any other material while in use.
- The WEEE logo means that this device contains electronic parts and it must be properly disposed of by following the instructions at https://www.zennio.com/en/legal/weee-regulation.
- This device contains software subject to specific licences. For details, please refer to http://zennio.com/licenses.